

**BALANCED PRESSURE  
THERMOSTATIC STEAM TRAP**

# DV1

---

**USER'S MANUAL**



 **MIYAWAKI INC.**

# SAFETY GUIDE

The Model DV1 is a balanced pressure thermostatic steam trap equipped with a membrane capsule (thermo element) and a bypass valve. The bypass valve can discharge a large quantity of condensate, which saves a great deal of start-up time.

The steam trap discharges the condensate automatically at a temperature 5 °C/9 °F (capsule H) or 15 °C/27 °F (capsule L) below saturation temperature.

In order to get maximum benefit from this product, be sure to read this manual before installing it.

The following warnings and cautions are shown at appropriate places in this manual.



Failure to observe this type of precaution may lead to serious injury or death.



Failure to follow this type of precaution can lead to injury or damage to equipment and property.

## Table of Contents

1	SPECIFICATIONS AND MARKINGS	1
2	CONSTRUCTION DETAILS	2
3	INSTALLATION	3
4	OPERATION	4
5	MAINTENANCE	5
6	TROUBLESHOOTING	9
7	WARRANTY	10
8	SERIAL NUMBER (S. No.) DESIGNATION	11
9	GUIDANCE FOR READING SPECIAL PRODUCT NAME	12

# 1 SPECIFICATIONS AND MARKINGS

---



## WARNING

**Be sure not to use this product at higher pressures than the specified maximum operating pressure (PMO) or at temperatures higher than the specified maximum operating temperature (TMO).**


The following items are displayed on the name label or the side of the product. Check the operating characteristics to avoid misuse of the product.

- 1) Maximum allowable pressure (PMA): 1.0 MPa (145 psig)
- 2) Maximum allowable temperature (TMA): 185 °C (365 °F)
- 3) Maximum operating pressure (PMO): 1.0 MPa (145 psig)
- 4) Maximum operating temperature (TMO): 185 °C (365 °F)
- 5) Size: 15 mm (1/2"), 20 mm (3/4"), 25 mm (1")
- 6) Year of production: The two leftmost digits in the four-digit or nine-digit 'S. No.' are the last two digits of the year of production.
- 7) Flow direction: Shown by an arrow
- 8) Body material: Stainless steel SCS13A/CF8
- 9) Model : Showing the product model name

- Some pictures and illustrations in this manual are examples of DV1 models. For more details regarding dimensions and other specifications, please refer to the catalog.

The model DV1 fully complies with the requirements of the European Pressure Equipment Directive 2014/68/EU. It is classified according to Article 4, Section 3 of the PED, which does not allow to bear the CE marking.

## 2 CONSTRUCTION DETAILS



- |   |                   |                   |
|---|-------------------|-------------------|
| 1. Body                                 | 9. Cover Bolt     | 17. Gland Nut     |
| 2. Cover                                | 10. Bonnet        | 18. Handle        |
| 3. Membrane Capsule<br>(Thermo Element) | 11. Disc          | 19. Nut           |
| 4. Valve Seat                           | 12. Valve         | 20. Nut           |
| 5. Stop Spring                          | 13. Spindle       | 21. Name Plate    |
| 6. Screen                               | 14. Grand Packing | 23. Plate         |
| 7. Seat Gasket                          | 15. Plate         | 24. Spring Washer |
| 8. Cover Gasket                         | 16. Gland Bush    | 25. Washer        |

### 3 INSTALLATION

---



#### WARNING

Pay very careful attention when working in hazardous environments. There is a risk of explosion and the possibility of dangerous gases leaking. Always check whether the pipeline contains flammable, high pressure or high temperature materials before starting to work.


- Make sure that isolation valves are installed on both the upstream and downstream lines.



#### CAUTION

Before installing the product, open both isolation valves and the bypass valve, if one exists, to blow out any debris or dirt inside the pipeline. After blowing out the line, before starting to work, close the isolation valves and allow time for the temperature to drop to a safe working temperature.

When installing the product, be sure to leave clearance for maintaining it.



- 1) Remove the dustproof seals covering both connections.  
※Products shipped in plastic bags may not have dustproof seals.
- 2) Check the flow direction indicated on the body.
- 3) The DV1 can be used for both horizontal and vertical lines. In horizontal lines, install the DV1 so that the handle faces up or at least sideways. If the DV1 is installed with the handle facing down, it will cause the trap to malfunction. Make sure to maintain a slight slope to the line, so that any condensate will flow smoothly to the trap.
- 4) Open the isolation valve on the upstream line slowly and make sure the product works normally.

## 4 OPERATION

---



### CAUTION

**Before starting operation, open the bypass valve or blow valve completely and blow off the scale in the piping.**

#### 4.1 Operation procedure

- 1) After blowing off the scale from the piping, close the bypass valve or blow valve.
- 2) Open the isolation valve on the trap outlet side.
- 3) Open the isolation valve on the trap inlet side.

#### 4.2 Stop procedure

- 1) Close the isolation valve on the trap inlet side.
- 2) Close the isolation valve on the trap outlet side.

\* When stopping for a long time, completely drain the condensate from the piping and trap and close the valves before and after the trap.



### CAUTION

**In normal operation use the DV1 with the bypass valve closed (with the handle turned fully clockwise).**

**If the DV1 is used for a long time with the bypass valve open, there is a possibility that parts such as the disc may be damaged.**

When the handle is turned counterclockwise (in the direction indicated by the BLOW arrow on the name plate), the bypass valve will open and any air, condensate or steam in the trap will be discharged quickly. Scale that has accumulated in the screen can also be removed.

When the handle is turned fully clockwise (in the direction indicated by the TRAP arrow on the name plate), the bypass valve will close and it will operate as a steam trap. In normal operation, the DV1 should be used with the bypass valve closed.

## 5 MAINTENANCE

---



### WARNING

- Before removing the trap from the pipe or disassembling it, be sure to close the isolation valves. Then, release the residual pressure from the trap body (make sure that the pressure in the main body is equal to the atmospheric pressure). After it has fully cooled down (after the temperature of the main body has reached ambient temperature), confirm for safe conditions and then begin to work.
- Even when the isolation valves are closed, there may be residual internal pressure due to leaks from the isolation valves. Therefore, be very careful.



### CAUTION

- When replacing parts, make sure the replacement parts are supplied by MIYAWAKI.

The performance of steam traps deteriorates gradually over time due to wear, corrosion or dirt accumulating around the valve and the valve seat. Please conduct periodic diagnosis of traps in order to keep steam control systems and equipment working well.

### 5.1 Tools for Diagnosis Steam Traps

#### ■ Dr. Trap

Dr. Trap is a sophisticated steam trap management system for diagnosing steam traps automatically by measuring the vibration and temperature of the steam trap. Survey results are stored in the testing equipment and transferred to a steam trap analysis software. The software aggregates and analyses steam trap survey data, identifying faulty steam traps, providing steam loss and financial loss data, estimating CO<sub>2</sub> emissions corresponding to leaking steam traps and providing many other analyze possibilities to manage the steam trap population easily.

#### ■ Dr. Trap Jr.

Dr. Trap Jr. is an inexpensive and easily to handle steam trap diagnostic system consisting of an ultrasonic checker, temperature probe and a sophisticated analysis software. The software allows to determine the condition of a steam trap, to estimate steam and financial losses and the related CO<sub>2</sub> emissions.

For more details, please, check our homepage:

<https://www.miyawaki.net/en/products/steam-trap-management-system>

or ask our local representative.

## 5.2 Repairs

When a trap fails, it is necessary to clean the internal parts and to replace damaged parts. Take the failed trap apart following the steps below.

### 5.2.1 Disassembling the trap

- 1) Remove the cover bolts (9) and remove the cover (2) from the body (1).
- 2) Remove the stop spring (5) from the cover (2) and take out the membrane capsule (thermo element) (3). Then loosen and remove the valve seat (4).
- 3) Remove the cover gasket (8), seat gasket (7) and screen (6).

### 5.2.2 Disassembling the bypass housing

- 1) Remove the nut (20). Then remove the plate (23) and the handle (18).
- 2) Loosen the gland nut (17) and the bonnet (10) and remove both parts.
- 3) Turn the spindle (13) clockwise and remove it.
- 4) Remove the gland bush (16), the gland packing (14) and the plate (15).



#### **CAUTION**

**Clean the Body (1) and Cover (2) with care not to damage the sealing surfaces. Scratches on the sealing surface may cause steam leakage.**

Take appropriate measures according to “6. Troubleshooting”. After cleaning the trap and replacing damaged parts, reassemble the parts in reverse order as follows. Refer to the torque table for each part.

### 5.2.3 Reassembling the bypass housing

- 1) Screw the spindle (13) into the bonnet (10) until the valve (12) touches the bonnet lightly.
- 2) Screw the bonnet (10) into the body (1).
- 3) Place the plate (15), the gland packing (14) and the gland bush (16) in the bonnet (10) in this order. Then tighten the gland nut (17).
- 4) Put the handle (18), the plate (23), the spring washer (24) and the washer (25) on the spindle (13). Then tighten the nut (20).

### 5.2.4 Reassembling the trap

- 1) Attach the screen (6) to the body (1).
- 2) Attach the seat gasket (7) to the body (1) and screw the valve seat (4) into the body.
- 3) Put the membrane capsule (thermo element) (3) on the valve seat (4).
- 4) Install the stop spring (5) on the cover (2).  
\* Since the stop spring (5) is curved, fit it in the correct orientation as shown in the illustration. (The trap will not work properly if the stop spring (5) is installed in reverse.)
- 5) Mount the cover gasket (8) on the body (1), put the cover (2) on the body (1) and tighten the cover bolts (9).




### Torque table

Parts	Tools	Across the flats	Torque
Valve Seat (4)	Torque wrench	17 mm (0.67")	22 N·m
Cover Bolt (9)	Torque wrench	10 mm (0.39")	9 N·m
Bonnet (10)	Torque wrench	21 mm (0.83")	60 N·m
Gland Nut (17)	Torque wrench	24 mm (0.95")	20 N·m



### CAUTION

When reassembling always replace the Gaskets (7 and 8) with new ones. Tighten the Cover Bolts (9) evenly crosswise.



## 6 TROUBLESHOOTING

Problem		Possible cause	Solution
Steam leaks or blows through.		Too high operating pressure.	Check operating conditions. Reduce the inlet pressure or change to another trap with higher pressure capability.
		A foreign object is caught between the valve of the membrane capsule (thermo element) (3) and the valve seat (4).	Close the inlet valve once, cool the trap, and then open the inlet valve. (Blow off) If the foreign matter cannot be removed even after blow off, disassemble and clean the membrane capsule (thermo element) (3) and valve seat (4). *1
		The valve of the membrane capsule (thermo element) (3) and/or the valve seat (4) are damaged.	Replace the valve seat (4) and/or the membrane capsule (thermo element) (3) with new ones.
		The membrane capsule (thermo element) (3) is damaged.	Replace the membrane capsule (thermo element) (3).
		The handle (18) has been poorly tightened.	Tighten the handle (18) clockwise (TRAP side).
		Dirt accumulated around the disc (11) or body (1).	Clean the parts.
		Damage, erosion or corrosion of the disc (11) or body (1) in the disc seal area.	Replace both parts.
		Improper installation.	Check and reinstall with the handle pointing up or sideways.
Steam leaks from the body.	From the connection between the body and cover	The cover bolts (9) are loose.	Tighten the cover bolts (9). *2
		The cover gasket (8) is damaged.	Replace the cover gasket (8).
		The body (1) or gasket seal area of the cover (2) are damaged.	Replace the body (1) and/or the cover (2).
	From the joint between the body and the bonnet.	The bonnet (10) is loose.	Tighten the bonnet (10). *2
		The body (1) or the sealing area of the bonnet (10) are damaged.	Replace the body (1) and/or the bonnet (10).
Steam leaks from the body.	From the gland packing section.	The gland nut (17) is loose.	Tighten the gland nut (17).
		The gland packing (14) is damaged.	Replace the gland packing (14).
		The bonnet (10) or sealing area of the spindle (13) are damaged.	Replace the bonnet (10) and/or the spindle (13).
Insufficient condensate discharged, or no condensate discharged.		Improper installation direction	Reinstall the trap correctly.
		Dirt has built up on or around the valve seat (4).	Clean the valve seat (4).
		The screen (6) is clogged.	Clean the screen (6).
		The membrane capsule (thermo element) (3) is damaged.	Replace the membrane capsule (thermo element) (3).
		Insufficient condensate capacity.	Replace the trap with a larger capacity trap.

\*1 and \*2: Refer to the torque table in Section 5, "Maintenance" to retighten the parts with the correct torque.

## **7 WARRANTY**

---

### **7.1 Warranty period**

The warranty period is 18 months after shipment or 12 months after installation, whichever occurs first.

### **7.2 Details of the warranty**

If the product stops working correctly within the warranty period, we will repair or replace the product free of charge if the cause of the trouble is not one of the following items.

- 1) The precautions described in this manual were not observed.
- 2) User's errors or mistakes such as an inappropriate installation or incorrect handling, or an excessively large impact caused by dropping
- 3) Problems caused by devices or equipment other than MIYAWAKI's, or a disallowed use environment
- 4) When a repair or modification has been performed by anyone other than MIYAWAKI or people who are authorized to make such repairs
- 5) Intrusion of salt or other substances that promote significant rust or corrosion or problems from fluids that contain the same substances
- 6) Consumable parts such as Packing, Gasket, O-ring, Diaphragm, etc.
- 7) Attachment or accumulation of foreign matter in the pipe, such as dust and scale
- 8) Problems from fires, natural disasters, or other force majeure which is not MIYAWAKI's responsibility


### **7.3 Warranty limitation**

The remedy available under the warranty shall not exceed the sales price of the products delivered, for any cause whatsoever.

## 8 SERIAL NUMBER (S. No.) DESIGNATION

The following 4-digit or 9-digit 'S. No.' is displayed on the product.

- For 4-digit display




Example of serial number designation

1 7 1 1 → Jan.1, 2017

2 9 X M → Oct. 21, 2029

- For 9-digit display



Example of serial number designation

1 7 1 1 2 C 0 2 0 → Jan., 2017

2 9 X 0 5 M 0 5 0 → Oct., 2029

### Month designation system

Month	1	2	3	4	5	6	7	8	9	10	11	12
Symbol	1	2	3	4	5	6	7	8	9	X	Y	Z

### Day designation system

Day	1	2	3	4	5	6	7	8	9	10	11	12
Symbol	1	2	3	4	5	6	7	8	9	A	B	C

Day	13	14	15	16	17	18	19	20	21	22	23	24
Symbol	D	E	F	G	H	J	K	L	M	N	O	P

Day	25	26	27	28	29	30	31
Symbol	Q	R	S	T	U	V	W

## 9 GUIDANCE FOR READING SPECIAL PRODUCT NAME




Table 1 Symbol description

Suffix	Special contents
A	Trap for high-pressure gas installed property (only for Gas Trap)
C	Blow valve attached
K	Change of gasket
L	Special face to face dimension
M	Change of parts material
P, T	Change of operating pressure, temperature, condensate capacity, etc
R	Change of screen mesh
V	Change of air vent
X	Other than mentioned above or complex of special contents above

- 
- For any questions about the product that you purchased or about the details in this user's manual, please contact the following.
  - © 2020 MIYAWAKI INC.  
This user's manual may not be reproduced or copied in whole or in part, without the written consent of MIYAWAKI INC.
  - Some special specifications of the product you have, may found to be different from the ones in the user's manual. If you have any question, please contact MIYAWAKI, our local authorized agent, or the company where you purchased the product.
  - In the interest of the development and improvement of our products, MIYAWAKI Inc. reserves the right to change the specification of the products without prior notice.
-



If you need any assistance regarding this manual, please contact  
MIYAWAKI INC.'s International Sales Dept. or its local representative.  
By scanning QR Code, you can access inquiry form.



**INTERNATIONAL SALES DEPT.**  
2-1-30, Tagawakita, Yodogawa-ku, Osaka, 532-0021, Japan  
Tel: +81-6-6302-5549  
[www.miyawaki-inc.com/en](http://www.miyawaki-inc.com/en) e-mail: [export@miyawaki-inc.co.jp](mailto:export@miyawaki-inc.co.jp)

EU Importer and Authorized representative:



**MIYAWAKI GmbH**

Birnbaumsmühle 65, 15234 Frankfurt (Oder), Germany  
Tel: +49-335-4007-0097  
[www.miyawaki.de](http://www.miyawaki.de) e-mail: [info@miyawaki.de](mailto:info@miyawaki.de)

China Importer and Authorized representative:



**MIYAWAKI WEST Co., Ltd.**

Room 902, Building 8, Huaqing Chuangzhi Park, No.3 Qingyan Road, Huishan District,  
Wuxi City Jiangsu Province, China  
Tel: +86-510-8359-5125  
[www.miyawaki-inc.com.cn](http://www.miyawaki-inc.com.cn) e-mail: [mywkwest@miyawaki-inc.com.cn](mailto:mywkwest@miyawaki-inc.com.cn)